



Hamilton Beach 70730 Bowl Replacement

This is the guide to replace the bowl of your Hamilton Beach Bowl Scraper Food Processor.

Written By: Mack Bernard



INTRODUCTION


The bowl is an important piece of the food processor. Without it the food cannot be chopped or sliced. If the bowl is cracked or chipped it must be replaced.

Step 1 — Bowl



- Remove the cover by turning it in the counterclockwise direction.

Step 2



- Remove the bowl scraping mechanism by simply grabbing the middle section and lifting.

Step 3



- Remove the blade mechanism by lifting it off of the blade shaft.

Step 4



- Place hands on bowl and turn it gently, but firmly, counter-clockwise.

Step 5



- ⓘ Make sure there is no food or grime along the outside sides of the bowl or the base.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 05:41:25 PM.